

HD24



Trk 12 00:02:09.21
Mark 5 00:15:32.12

BATTERY LINK BACKLIGHT

Play/Stop or
Rec/Play

LEGEND
Shift
Normal

TRACK

< Track Track > Clr All Recs Auto-Input Mode All-Input Mode ANY SOLO Toggle Screen
Rec Ready

IN OUT Footswitch Mode Rehearse Mode

MARKERS

Shift Prev Marker Add Marker Clr Markers
Go to Mark Next Marker

Scroll (Frames)
Scroll (Seconds)

FRONTIER

Go to start Fast Fwd Stop Play Record
Rewind